

2nd EDITION

A.P. 1578C, K, L, M, N. & P. —P.N.

**PILOT'S NOTES**  
FOR  
**WELLINGTON**  
III, X, XI, XII, XIII & XIV  
TWO HERCULES XI, VI, XVI or XVII ENGINES



PROMULGATED BY ORDER OF THE AIR COUNCIL

*Handwritten signature*

**RESTRICTED**  
**(FOR OFFICIAL USE ONLY)**

SAPPHIRE PRODUCTIONS, 16 THE FRIARS, CHIGWELL, ESSEX.  
England 01-500 1857

Crown Copyright. Reproduced with permission of the  
Controller of Her Majesty's Stationery Office  
(1077) W. 8028/2845 9,000 1744 C.P. Ltd. Gp. 784

## AMENDMENTS

Amendment lists will be issued as necessary and will be gummed for affixing to the inside back cover of these notes.

Each amendment list will include all current amendments and will, where applicable, be accompanied by gummed slips for sticking in the appropriate places in the text.

Incorporation of an amendment list must be certified by inserting date of incorporation and initials below.

A.L. NO.	INITIALS	DATE	A.L. NO.	INITIALS	DATE
1			7		
2			8		
3			9		
4			10		
5			11		
6			12		

## NOTES TO USERS


THIS publication is divided into five parts: Descriptive, Handling, Operating Data, Emergencies, and Illustrations. Part I gives only a brief description of the controls with which the pilot should be acquainted.

These Notes are complementary to A.P.2095 Pilot's Notes General and assume a thorough knowledge of its contents. All pilots should be in possession of a copy of A.P.2095 (see A.M.O. A93/43).

Words in capital letters indicate the actual markings on the controls concerned.

Additional copies may be obtained from A.P.F.S., Fulham Road, S.W.3, by application on R.A.F. Form 294A, in duplicate, quoting the number of this publication in full—A.P. 1578C, K, L, M, N. & P.—P.N.

Comments and suggestions should be forwarded through the usual channels to the Air Ministry (D.T.F.).



WELLINGTON

## WELLINGTON III, X, XI, XII, XIII AND XIV—PILOT'S NOTES

*2nd Edition. This edition supersedes all previous issues.*

### LIST OF CONTENTS

#### PART I—DESCRIPTIVE

	<i>Para.</i>
INTRODUCTION .. .. .	1
FUEL AND OIL SYSTEMS	
Fuel tanks .. .. .	2
Balance cocks .. .. .	3
Tank cocks .. .. .	4
Fuel handpump .. .. .	5
Fuel gauges .. .. .	6
Fuel pressure warning lights .. .. .	7
Oil tanks .. .. .	8
Oil tank low level indicators .. .. .	9
MAIN SERVICES	
Hydraulic system .. .. .	10
Pneumatic system .. .. .	11
Electrical system .. .. .	12
AIRCRAFT CONTROLS	
Flying controls .. .. .	13
Trimming tabs .. .. .	14
Interconnection of elevator trimming tabs and flaps .. .. .	15
Undercarriage control .. .. .	16
Undercarriage indicator .. .. .	17
Undercarriage warning horn and light .. .. .	18
Flap control .. .. .	19
Wheel brakes .. .. .	20
Flying control locking gear .. .. .	21

## PART I—continued

ENGINE CONTROLS	Para.
Throttle and mixture controls .. .. .	22
Propeller controls .. .. .	23
Supercharger control .. .. .	24
Carburettor air intake control .. .. .	25
Cowling gill controls .. .. .	26
Oil cooler shutters (Mk. III aircraft only) ..	27
Slow-running cut-outs .. .. .	28
Priming pumps .. .. .	29
Engine starter and booster-coil pushbuttons ..	30
Boost gauge reversal control .. .. .	31

## OTHER CONTROLS

Bomb doors .. .. .	32
Bomb/depth-charge release control .. .. .	33
Torpedo release controls (Mk. XI and XIII aircraft only) .. .. .	34
Heating controls .. .. .	35
Landing lamps .. .. .	36
Reconnaissance flares .. .. .	37

## PART II—HANDLING INSTRUCTIONS

Management of fuel and auxiliary oil systems ..	38
Preliminaries .. .. .	39
Starting engines and warming up .. .. .	40
Testing engines and installations .. .. .	41
Check list before taxiing .. .. .	42
Check list before take-off .. .. .	43
Take-off .. .. .	44
Climbing .. .. .	45
General flying .. .. .	46
Stalling .. .. .	47
Diving .. .. .	48
Check list before landing .. .. .	49
Approach .. .. .	50
Mislanding .. .. .	51
After landing .. .. .	52
Beam approach .. .. .	53

## PART III—OPERATING DATA

Engine data—Hercules XI (Mk. III aircraft only)	54
Engine data—Hercules VI, XVI and XVII ..	55
Flying limitations .. .. .	56
Position error corrections .. .. .	57
Maximum performance .. .. .	58
Economical flying .. .. .	59
Fuel capacities and consumption .. .. .	60
Static vent speeds .. .. .	61

## PART IV—EMERGENCIES

Engine failure during take-off .. .. .	62
Engine failure in flight .. .. .	63
Feathering .. .. .	64
Unfeathering .. .. .	65
Undercarriage emergency operation .. .. .	66
Bomb and depth-charge jettisoning .. .. .	67
Fuel jettisoning .. .. .	68
Parachute exits .. .. .	69
Crash exits .. .. .	70
Air/sea rescue equipment .. .. .	71
Flotation gear .. .. .	72
Ditching .. .. .	73
Turret external rotation .. .. .	74
Fire extinguishers .. .. .	75

## PART V—ILLUSTRATIONS

	Fig.
Pilot's instrument panel .. .. .	1
Cockpit—port side .. .. .	2
Cockpit—starboard side (from above) .. .. .	3
Fuel system diagram .. .. .	4

## PART I

## DESCRIPTIVE

NOTE.—The numbers quoted in brackets after items in the text refer to the key numbers of the illustrations in Part V.

## INTRODUCTION

1. The Wellingtons III and X are equipped as medium bombers (some are used for training purposes), and the Wellingtons XI, XII, XIII and XIV for general reconnaissance duties with Coastal Command.

The Mks. XI and XIII carry torpedoes, alternatively depth-charges, and operate by day; the Mks. XII and XIV are each fitted with a Leigh light in the mid-under turret and carry depth charges only.

The corresponding Marks of Hercules engine are as follows:

Mark III	.. ..	Hercules XI
Mark X	.. ..	Hercules VI or XVI
Mark XI	.. ..	Hercules VI or XVI
Mark XII	.. ..	Hercules VI or XVI
Mark XIII	.. ..	Hercules XVII
Mark XIV	.. ..	Hercules XVII

Each is fitted with Rotol electric or de Havilland hydro-matic fully feathering propellers. Some Mk. III aircraft have Rotol hydraulic propellers.

## FUEL AND OIL SYSTEMS (see Fig. 4)

## 2. Fuel tanks

- (i) *Normal tanks.*—Two main tanks in each wing supply the feed pipe through non-return valves, and a tank in each nacelle supplies the same pipe through a cock controlled from the fuselage. These three tanks on each side supply the engine-driven pumps through main tank cocks (Cp

## PART I—DESCRIPTIVE

and Cs), and the pumps supply the engines through corresponding master cocks (Ep and Es). The capacities of these tanks are as follows:

2 Front wing tanks	..	150 gallons each
2 Rear wing tanks	..	167 gallons each
2 Nacelle tanks..	..	58 gallons each

(ii) *Auxiliary tanks:*

(a) *Mk. III and X aircraft.*—In addition to the normal tanks, an auxiliary self-sealing tank of 140 gallons capacity can be installed in each outer bomb cell. These tanks supply the main feed line for each engine through corresponding non-return valves and on-off cocks (Dp and Ds). Certain aircraft fitted with a high-capacity bomb beam carry an auxiliary tank of 295 gallons capacity in the bomb compartment and this is connected to the auxiliary tank cock (Ds). Tropicalised Mk. X aircraft carry two 55-gallon tanks when on reinforcing flights.

(b) *Mk. XI, XII, XIII and XIV aircraft.*—Up to three auxiliary tanks can be carried, one in each bomb cell. Fuel in these tanks flows through corresponding non-return valves and on-off cocks (Dc, Dp and Ds) into the suction balance pipe and so to the main feed lines. The following alternative tankages can be carried:

- (i) One 185-gallon tank in the centre bomb cell.
- (ii) Two 140-gallon tanks, one in each outer bomb cell.
- (iii) One 185-gallon tank in the centre bomb cell and one 140-gallon tank in the starboard bomb cell (when only one torpedo is carried).
- (iv) Three 185-gallon tanks, one in each bomb cell (for reinforcing flights).

The centre bomb cell tank is divided into two partially isolated cells. The three-way selector cock (Dc) allows fuel to be drawn from only one cell at a time, but on some aircraft the two cells are connected separately to the two cocks Dp and Ds and can, therefore, be used simultaneously.

## PART I—DESCRIPTIVE

3. **Balance cocks.**—The fuel systems for the port and starboard engines are connected by a pressure balance cock (A) (63) and a suction balance cock (B). These cocks are normally kept shut, but the pressure balance cock (A) may be opened if failure of either engine pump is suspected, and the suction balance cock (B) may be opened to enable either engine pump to be fed by tanks on the opposite side.
  4. **Tank cocks.**—The pilot can shut off the fuel supply to an engine by closing the corresponding engine master cock (Ep or Es) (61). The pressure balance cock (A) is also under his control. The remainder of the cocks, however, are under the control of the crew and are as follows:
    - (i) The main tank cocks (Cp and Cs), remotely controlled by handles at the port and starboard sides of the fuselage, immediately forward of the spar centre section.
    - (ii) The nacelle tank cocks controlled by cables beside the main tank cock handles.
    - (iii) The suction balance cock (B) and the auxiliary tank cocks (Dc, Dp and Ds) immediately aft of the spar.
- NOTE.—Cocks Cp, Cs and B are three-position cocks, but may be regarded as ON-OFF cocks, as two positions only are used. Cock Dp on Mark X aircraft fitted with two 55-gallon tanks in the port bomb cell is a three-position cock.
5. **Fuel handpump.**—There is a fuel handpump aft of the spar for priming the fuel system (if necessary) and supplementing the supply of either engine-driven pump. The handpump is connected between the suction and pressure balance pipes on the port side of the pressure balance cock (A); this cock must be open to feed the starboard engine from the handpump, and the suction balance cock (B) must be open for the handpump to draw from the starboard tanks. An ON-OFF cock (H) controls the supply from the suction balance pipe to the handpump.
  6. **Fuel gauges.**—Contents gauges for all tanks except the nacelle and centre bomb cell tanks are fitted. To obtain readings operate the pushbutton (9) on the pilot's instrument panel or the pushbutton near the gauges on the electrical panel.

## PART I—DESCRIPTIVE

7. **Fuel pressure warning lights.**—Two fuel pressure warning lights (22), one for each engine, are fitted on the right-hand side of the pilot's instrument panel and come on when the pressure drops below  $1\frac{1}{4}$  lb./sq.in. They are not fitted on Mk. III aircraft.
8. **Oil tanks.**—Each engine has one oil tank, holding 16 gallons, mounted on the front of the nacelle fuel tank. An auxiliary oil tank in the fuselage, aft of the spar, for use on long-range flights, holds 15 gallons and incorporates a handpump to enable oil from the auxiliary tank to be transferred to either of the nacelle tanks through a two-way selector cock in the delivery pipe nearby. (For management of auxiliary tank and pump *see* para. 38.) The oil dilution valves are operated by two pushbuttons, one for each engine, on the electrical panel aft of the cockpit.
9. **Oil tank low-level indicators.**—Two red warning lights (16), one for each main oil tank, are fitted on the pilot's instrument panel and a duplicate pair on the rear side of the wing spar. These light up when the oil reaches a dangerously low level and give warning that the handpump must be used to replenish the main tanks.

## MAIN SERVICES

### 10. Hydraulic system

- (i) *Mk. III and X aircraft.*—Two engine-driven hydraulic pumps are mounted on the port engine; one pump operates the two gun turrets and the other pump supplies the following general services:
  - Undercarriage
  - Flaps
  - Bomb doors
  - Carburettor air-intake shutters
  - Windscreen wipers.
- (ii) *Mk. XI, XII, XIII and XIV aircraft.*—There are three pumps driven by the port engine, one pump supplies the services listed above, a second operates the rear gun turret, and the third pump operates the front gun turret on Mk. XI and XIII aircraft and the mid-under turret on Mk. XII and XIV aircraft.

## PART I—DESCRIPTIVE

(iii) *All Marks*.—A handpump (81) to the right of the pilot's seat will operate any of the general services through the normal lines if the engine-driven pump has failed, or if the port engine is stopped. If the normal hydraulic system fails to operate these services by either the engine-driven pump or the handpump, the undercarriage may be lowered by an emergency hydraulic system (*see* para. 66)

11. **Pneumatic system**.—Two compressors are driven by the starboard engine; one operates the automatic controls and the other supplies pressure for the wheel brakes and the fuel jettison valves. A suction pump is driven by each engine, one pump operating the blind flying instrument panel and the other acting as a reserve. A pump change-over cock control (84) is fitted to the right of the seat and there is a gauge (25) to the right of the centre instrument panel.

### 12. Electrical system

(i) *Mk. III aircraft*.—A 1,500 watt generator on the starboard engine supplies 24 volts D.C. for the following services:

- All lighting
- Engine starting
- Propeller feathering and pitch changing (Rotol electric type)
- Pressure-head heating
- Fuel contents gauges
- Undercarriage and flap indicators
- Radio and beam approach
- Fire-extinguisher system
- Camera heating
- Oil dilution valves
- Operation of flotation gear
- Release and inflation of dinghy

(ii) *Mk. X aircraft*.—Two 1,500 watt generators, one on each engine, supply 24 volts D.C. for the above general services.

(iii) *Mk. XI and XIII aircraft*.—One 1,000 watt generator on each engine supplies 24 volts D.C. for the above general services and A.C. for the special radio equipment.

## PART I—DESCRIPTIVE

(iv) *Mk. XII and XIV aircraft*.—Two 1,500 watt generators, one on each engine, supply 24 volts D.C. for the above general services. In addition, the port engine generator supplies A.C. for the special radio equipment.

D.C. for the Leigh light is supplied by a separate generator on the starboard engine.

(v) *All Marks*.—The external battery socket for ground starting of the engines is under a hinged panel, on the starboard side of the fuselage, below the main plane leading edge. The ground/flight switch is on the starboard side of the fuselage, just forward of the main spar.

### AIRCRAFT CONTROLS

13. **Flying controls**.—These are of the conventional type. The rudder bar is adjustable for reach by means of a star-wheel (35) at the rear of its mounting. This can be rotated in flight by the feet, clockwise rotation shortening the reach. Dual controls, coupled to the main controls, can be mounted on a special floor extension forward of the starboard seat.

14. **Trimming tabs**.—The elevator and rudder trimming tabs are operated by a single control (59) which works in the natural sense. There is a fine adjustment control (60) for the elevator tabs to the left of this control. The aileron trimming tab (port only) control is a rotatable handle (65) with a lock-release grip, immediately outboard of the elevator and rudder trimming tab control, and works in the opposite way to the natural, i.e. turning clockwise raises the starboard wing.

15. **Interconnection of elevator trimming tabs and flaps**.—When the flaps are fully lowered they cause the aircraft to become "tail-heavy"; the flaps are, therefore, interconnected with the elevator tabs so that lowering of the flaps automatically raises the elevator tabs and counteracts the "tail-heaviness".

It is essential that the elevator trimming tab control *should not be forward* of the central position before the flaps are lowered, or damage to the tab control mechanism may result. On most aircraft a spring catch is fitted which allows the pilot to feel the central position on moving the control.

## PART I—DESCRIPTIVE

16. **Undercarriage control.**—Raising and lowering of the undercarriage and tailwheel is controlled by a lever (31) in the centre of the instrument panel which has automatic safety catches locking it in the UP or DOWN positions. These catches must be freed by the catch release before the lever can be operated. Each main wheel unit is provided with mechanical up and down locks which automatically lock the unit in the UP or DOWN position as soon as it is fully retracted or lowered. The locks are automatically released by hydraulic power immediately the undercarriage selector lever is moved to the UP or DOWN position. Correct operation of the locks is indicated by the normal undercarriage indicator, with the electrical circuit of which they are interconnected.
17. **Undercarriage indicator.**—On Mk. III aircraft the indicator (11) shows as follows:
- |                           |                    |
|---------------------------|--------------------|
| All units locked DOWN ..  | Three green lights |
| All units unlocked .. ..  | No lights          |
| All units locked UP .. .. | Three red lights   |
- but on the later Marks the indicator shows as follows:
- |                           |                    |
|---------------------------|--------------------|
| All units locked DOWN ..  | Three green lights |
| All units unlocked .. ..  | Three red lights   |
| All units locked UP .. .. | No lights          |
- The indicator switch (49) is interlocked so that it must be on when the ignition switches are on. The indicator DOWN lights are duplicated (on Mk. III aircraft the red lights are also duplicated, but not the tailwheel light), and in the event of failure of a lamp the duplicate set can be brought into circuit by pulling out (or pushing in) a knob in the centre of the dial case. In addition, counter-clockwise rotation of this knob operates a dimmer screen.
18. **Undercarriage warning horn and light.**—An electric horn behind the pilot's seat sounds and a red light beside the undercarriage indicator lights up if both throttles are closed and the undercarriage is not locked down. The horn can be tested by pressing the test pushbutton (8) with the indicator switch closed. The light goes out when the horn stops. The light is not fitted on Mk. III aircraft.

## PART I—DESCRIPTIVE

19. **Flap control.**—The flap control lever (29) is retained in its neutral position by a spring-loaded catch which is released for operation by depressing the knob. The flaps are interconnected with the elevator tab control (see para. 15). The flap indicator (36) is switched on by the undercarriage indicator switch.
20. **Wheel brakes.**—Twin operating levers (40) for the pneumatic wheel brakes are provided on the control column handwheel; they are compressed either singly or simultaneously to apply both brakes. The brakes can be applied in the fully locked position for parking by engaging the locking slide (41). The system provides for differential braking by virtue of rudder bar movement when taxiing. A triple pressure gauge (18), showing the main supply pressure and the pressure at each brake, is fitted on the right of the instrument panel.
21. **Flying control locking gear.**—The flying controls can be locked in their neutral position by means of a triangular spring-loaded frame, hinged beneath the window ledge on the port side of the cockpit, and a detachable hinged nuisance bar. When not in use, the former is secured by a strap and pin to the side of the cockpit, and the latter is stowed on the starboard side of the cabin gangway.

## ENGINE CONTROLS

22. **Throttle and mixture controls.**—The two throttle levers (46) are interconnected with the corresponding mixture control levers (53) so that if the throttle is moved out of the weak mixture cruising range, the mixture lever will, if in the WEAK position, return to the rich (NORMAL) position. On Hercules XVI and XVII installations there are no pilot's mixture control levers, control being fully automatic. An economical mixture strength is obtained by keeping at or below +2 lb./sq.in. boost. Pending the introduction of a warning light to indicate the economical cruising boost position of the throttle levers, a white line is painted on the quadrant and the levers. On certain modified engines a position midway between the climbing and economical cruising boost settings gives better



## PART I—DESCRIPTIVE

economy on the climb after the boost has fallen to +4 lb./sq.in., and this position will be indicated by a second white line. A friction lever (47) is provided for clamping the throttles in any position to prevent movement due to vibration.

### 23. Propeller controls

(i) The speed control levers (56), common to all three types of propeller, are at the rear of the engine control quadrant and are moved forward to increase r.p.m. The feathering pushbuttons (6 and 15) for the hydraulic types are on the instrument panel.

(ii) The controls for the electric propellers (if fitted) are on the instrument panel and are as follows:

(a) *Safety switches.*—These should always be ON in flight as they control the supply to the propeller pitch mechanism and feathering circuits. If an excessive load is applied during any operation, the safety switch is automatically thrown to OFF. If this happens the switch should be reset to ON at the end of about half-a-minute.

(b) *Selector switches.*—Each switch can be moved to three different positions other than the central one, in which the propeller operates in fixed pitch. The two lower positions are for manual INCREASE and DECREASE of the r.p.m. respectively, and when the switch is moved to either of these positions it must be held there until the desired r.p.m. are attained; on being released it will return to the central position. In the upper (AUTO) position, the propeller operates under constant speed control.

(c) *Feathering switches.*—These are moved upward for rapid feathering and will function whatever the position of the propeller selector switches. Feathering can be effected slowly, but using substantially less current, by holding the corresponding selector switch down to the left in the DECREASE r.p.m. position. In either case, when the propeller is fully feathered the selector switch should be set to central.

## PART I—DESCRIPTIVE

24. **Supercharger control.**—The control (54) aft of the throttle levers may be locked in either the MEDIUM (M ratio) or FULL (S ratio) positions by a spring catch which is released by depressing the lever. On Mk. XI, XII, XIII and XIV aircraft the control is locked in M ratio.
25. **Carburettor air intake control.**—The lever (55) at the side of the supercharger control may be locked in either the COLD or WARM positions by a spring-catch which is disengaged by depressing the lever. The shutters are hydraulically operated.
26. **Cowling gill controls.**—The gills are opened and closed by handles (37) which are turned anti-clockwise to open.
27. **Oil cooler shutters (Mk. III aircraft only).**—The oil cooler shutters are operated by "Exactor" hydraulic controls to the right of the pilot's seat.
28. **Slow-running cut-outs.**—The controls (57), which are spring-loaded handles, are aft of the engine control box and each must be pulled and held out to stop the corresponding engine after the throttle is closed and before switching off the ignition.
29. **Priming pumps.**—An induction system priming pump, for use when starting, is mounted in each engine nacelle. A three-way priming cock inside each undercarriage wheel housing allows for priming with high volatility fuel from an outside source.
30. **Engine-starter and booster-coil pushbuttons.**—These (5 and 17) are on the centre instrument panel.
31. **Boost gauge reversal control.**—If one of the boost gauges fails, the boost gauge of the other engine can be used in its stead by pulling out the boost gauge reversal control (28).

### OTHER CONTROLS

32. **Bomb doors.**—The bomb doors are operated by a handle (43) which can be moved to the OPEN or CLOSED position, after releasing the lock, by depressing the spring-loaded thumb-knob. The handle is coupled with the bomb release master switch (45) so as to prevent the release of bombs until the control is in the OPEN position.

33. **Bomb/depth-charge release control.**—The pilot can release the bombs or depth-charges by means of the pushbutton (42), provided that they have been selected by the bomb aimer and the master switch is on. (For jettisoning of bombs and depth-charges see para. 67.)
34. **Torpedo release controls (Mk XI and XIII aircraft only).** Two pushbuttons (39), for port and starboard torpedoes, are provided on the control column handgrip. Each is covered by a safety shield.
35. **Heating controls.**—Exhaust-heated air is supplied from both engines via ducts, from which branch pipes supply the various crew stations. The main supply is controlled by a push-pull rod at the wing spar extensions on each side of the fuselage. The pilot's supply is controlled locally by a knob (83) on the diffuser (58) below and slightly forward of his seat.
36. **Landing lamps.**—Two retractable landing lamps in the port wing are raised and lowered by an "Exactor" hydraulic control lever (66) which can be locked in any desired position by a spring-loaded catch which is released at the top of the lever. Either lamp can be lighted, the other acting as a reserve, by operating the three-position switch (44) on the port side of the cockpit.
37. **Reconnaissance flares.**—From three to eleven flares are stowed vertically in racks on the starboard side, immediately aft of the cabin, and the launching tube is mounted amidships on the starboard side of the fuselage. An alternative arrangement of three or six loaded flare chutes in the mid-turret position is fitted in certain aircraft and a flare launching switch panel is fitted in the bomb-aimer's compartment.

## PART II

## HANDLING INSTRUCTIONS

All handling speeds are quoted for aircraft with the static side of the A.S.I. connected to the pressure head. The equivalent speeds in knots are quoted in brackets. The corresponding speeds for aircraft with the A.S.I. connected to the static vent in the side of the fuselage are given in para. 61.

## 38. Management of fuel and auxiliary oil systems

## (i) Use of balance cocks :

(a) The pressure balance cock (A) should be turned ON only when an engine fails due to lack of fuel. It should be kept ON only if the engine cannot be supplied otherwise (i.e. if its pump has failed).

(b) The suction balance cock (B) should always be OFF unless it is necessary to feed either engine from tanks on the opposite side or, in certain cases, when auxiliary tanks are used.

## (ii) Normal fuel system

The following recommended procedure ensures the fullest possible use of fuel, and should be studied in conjunction with the Fuel System Diagram (Fig. 4) in Part V.

(a) The nacelle tanks should always be filled, even if it is unnecessary to carry full fuel capacity, and their contents held as a reserve until all main tanks are exhausted.

(b) The operation of the nacelle tank cocks should be checked after take-off to ensure that the wire controls function correctly in flight. The pre-flight check may have been satisfactory, but the flexing of the wings in flight may interfere with the movement of the wire controls.

(c) Take off and fly on the main tanks, with both balance cocks closed and the nacelle tank cocks OFF.

(d) When an engine commences to cut through lack of fuel (this will be indicated by the appropriate fuel pressure

## PART II—HANDLING INSTRUCTIONS

warning light) open the pressure balance cock (A). This will revive the engine immediately and there is, therefore, no danger in allowing an engine to splutter through lack of fuel, except when coming in to land.

(e) Pull ON both nacelle tanks.

(f) Turn OFF the pressure balance cock (A).

(g) Nacelle tank cocks should not be turned ON until one engine fails due to lack of fuel. This will ensure that the Captain will have a *known* amount of fuel when the main tank supply is exhausted.

(h) Nacelle tank cocks should, however, always be pulled ON before landing, if the sufficiency of fuel remaining in the wing tanks is, in doubt.

(iii) *When auxiliary fuel tanks are fitted.*

(a) Fuel in the auxiliary tanks should be used early in flight.

(b) The order of use of the tanks should be so arranged that both engines do not run short of fuel simultaneously (*see below*). In all cases, when one engine fades for lack of fuel (this will be indicated by the appropriate fuel pressure warning light), open the pressure balance cock (A) which will revive it immediately. This cock should be closed again as soon as the fresh supply has been turned ON.

(c) *Recommended order of use of auxiliary tanks:*

(1) *When an equal amount of fuel is available on each side of the suction balance cock:* (Two tanks of equal capacity in the outer bomb cells, or a 185-gallon tank in the centre bomb cell connected to cocks Dp and Ds.):

Both balance cocks must be kept OFF.

Shortly before the auxiliary tanks are due to run out, change over to the main tanks on one side and empty the auxiliary tank on the opposite side. Repeat this procedure for the second auxiliary tank. Turn OFF the auxiliary tank(s) when empty.

## PART II—HANDLING INSTRUCTIONS

(2) *When a greater amount of auxiliary tank fuel is available on the port side of the suction balance cock:*

(A 185-gallon tank in the centre bomb cell connected to cock Dc, and other auxiliary tanks):

Both balance cocks must be kept OFF.

If a 140-gallon tank is carried in the starboard bomb cell, empty the rear half of the 185-gallon tank first, and then change over to the front half; this will be done before the 140-gallon tank is empty. When the starboard auxiliary tank is empty, open the suction balance cock (B) and run both engines on the remaining auxiliary fuel. Shortly before the fuel is due to run out, turn ON the starboard main tanks, close the suction balance cock (B) and exhaust the auxiliary tanks on the port engine. Then change over to the port main tanks and turn OFF the auxiliary tanks.

NOTE.—This will mean that the starboard main tanks will empty first. When they do, both nacelle tanks remain as a known reserve, plus a small extra quantity in the port main tanks which in the last resort can be used for both engines by opening the suction balance cock (B).

(3) *When a greater amount of auxiliary tank fuel is available on the starboard side of the suction balance cock:*

(A 140-gallon tank in the starboard bomb cell and two 55-gallon tanks in the port bomb cell):

Both balance cocks must be kept OFF.

When the port auxiliary tanks are empty, open the suction balance cock (B) and run both engines on the remaining fuel. The procedure detailed in (2) above then applies, but in the reverse sense.

(4) *When a 185-gallon tank in the centre bomb cell is connected to cock Dc, or a 295-gallon tank is connected to cock Ds, and no other auxiliary tanks are carried:*

As (2) and (3) above, except that the suction balance cock (B) must be ON from the time of first changing over to the auxiliary tank. Shortly before the auxiliary tank is due

## PART II—HANDLING INSTRUCTIONS

to run out, the main tanks on the opposite side should be turned ON, the suction balance cock (B) turned OFF and the auxiliary tank exhausted on one engine. The final residual fuel will then be in the port or starboard main tanks according to the bomb cell in which the auxiliary tank is carried.

### (iv) *Emergency operation of wing fuel tanks:*

In the event of a wing tank being damaged, the following sequence of operations should be carried out :

- (a) Turn ON the suction balance cock (B).
- (b) If fuel remains in the damaged tank, turn OFF the main tank cock (C) on the good side so as to use up any remaining fuel in the damaged tank.

### (c) When the engines cut\*:

Turn OFF the main tank cock (C) on the damaged side.  
Turn ON the main tank cock (C) on the good side.

### (d) When the engines cut again\*:

Pull ON both nacelle tank cocks.  
Turn ON the main tank cock (C) on the damaged side.  
Turn OFF the suction balance cock (B).

\* Or earlier if considered advisable.

### (v) *Operation of auxiliary oil tank:*

After the first two hours of flight and thereafter every hour, the handpump should be operated so as to supply each main oil tank with about one gallon of oil.

## 39. Preliminaries

### (i) Check fuel cock settings in fuselage:

Main tank cocks (Cp and Cs)	.. ..	On
Nacelle tank cocks	.. ..	Off
Auxiliary tank cocks (Dp, Dc and Ds)	.. ..	Off
Suction balance cock (B)	.. ..	Off

## PART II—HANDLING INSTRUCTIONS

### (ii) If Rotol electric propellers are fitted check :

Master switches	.. ..	ON
Feathering switches	.. ..	NORMAL
Selector switches	.. ..	AUTO

- (iii) Check that undercarriage selector lever is locked DOWN.
- (iv) Switch on undercarriage and flap indicators and test undercarriage warning horn and light (if fitted).

## 40. Starting engines and warming up

- (i) Set pilot's engine master cocks (Ep and Es) ON and the pressure balance cock (A) OFF.

### (ii) Set engine controls as follows :

Throttles	.. ..	$\frac{1}{2}$ inch open
Mixture controls (if fitted)	.. ..	NORMAL
Propeller speed controls	.. ..	HIGH R.P.M.
Supercharger control	.. ..	MEDIUM
Carburettor air-intake control	.. ..	COLD
Cowling gills	.. ..	OPEN
Oil cooler shutters (Mark III aircraft only)	.. ..	Closed

- (iii) Have each engine turned slowly by hand for at least two revolutions of the propeller, in order to ensure that oil will not cause a hydraulic lock of pistons or sleeves.
- (iv) It is not necessary to prime the carburettors unless the aircraft has been standing for a week or more. If necessary, this must be done with the pressure balance cock (A) ON.
- (v) High volatility fuel (Stores ref. 34A/111) should be used for priming at air temperatures below freezing. Instruct the ground crew to work the induction system priming pump until the suction and delivery pipes are primed. This may be judged by an increase in resistance.
- (vi) Switch ON the ignition and press the starter and booster coil pushbuttons simultaneously for each engine in turn. Turning periods must not exceed 20 seconds, with a 30 seconds wait between each. The ground crew will prime

## PART II—HANDLING INSTRUCTIONS

the induction system of each engine while it is being turned, and the engine should start after the following number of strokes if cold:

Air temp. °C : \* +30 +20 +10 0 -10 -20

### A.M. Type B (small) pump

Normal fuel	3	4	7	12		
High volatility fuel				4	8	18

### Type K40 (large) pump

Normal fuel	1	1	2	3		
High volatility fuel				1	2	5

- (vii) Release the starter button as soon as the engine fires. It will probably be necessary to continue priming after the engine has fired and until it picks up on the carburettor.
- (viii) As soon as the engine is running satisfactorily, release the booster coil button and get the ground crew to screw down the priming pump, turn OFF the priming cock and close the cowling door.
- (ix) Open the engine up slowly to 1,000 r.p.m. and warm up at this speed.

#### 41. Testing engines and installations

##### While warming up:

- (i) Check temperatures and pressures, and test operation of the hydraulic system by lowering and raising the flaps.

NOTE.—The following comprehensive checks should be carried out after repair, inspection, other than daily, or otherwise at the pilot's discretion. Normally they may be reduced in accordance with local instructions.

After warming up to at least 15°C oil temperature and 120°C cylinder temperature, for each engine in turn:

- (ii) Open up to 1,500 r.p.m. and exercise and check operation of the two-speed supercharger. (On Mark XI, XII, XIII and XIV aircraft this will not be possible.) Oil pressure should drop momentarily at each change.
- (iii) At maximum weak continuous boost (but in rich mixture) exercise and check operation of the constant-speed propeller.

## PART II—HANDLING INSTRUCTIONS

- (iv) With the propeller control fully forward open the throttle fully and check take-off boost and static r.p.m.
- (v) Throttle back to maximum rich continuous boost and test each magneto in turn. The drop should not exceed 50 r.p.m.

#### 42. Check list before taxiing

Brake pressure	.. ..	100 lb./sq.in (minm.).
Hatches	.. ..	Closed
Fuel	.. ..	Check contents
Pressure head heater	.. ..	ON

#### 43. Check list before take-off

T—Trimming tabs	.. ..	All neutral
M—Mixture controls	.. ..	NORMAL
P—Propeller controls	.. ..	Levers fully forward Master switches ON Selector switches AUTO
F—Fuel pressure balance cock	.. ..	OFF (down)
Superchargers	.. ..	MEDIUM
Carburettor air intakes	.. ..	COLD
F—Flaps	.. ..	20° down
Auto-pilot	.. ..	Cock—OUT Clutch—IN Main switch—OFF
Gills	.. ..	One-third OPEN
Oil cooler shutters (Mk. III aircraft only)	.. ..	Open as necessary
Throttle lever friction device	.. ..	Pulled back.

#### 44. Take-off

- (i) At 29,000 lb. get the tail well up and counteract any tendency to swing right by use of the rudder. If necessary, the starboard throttle should be opened slightly ahead of the port throttle.
- (ii) At 33,000 lb. and over, the tendency to swing right is more pronounced and the aircraft should not be pulled off the ground at a speed lower than 85 m.p.h. (75 knots) I.A.S.

## PART II—HANDLING INSTRUCTIONS

- (iii) Increase speed to 125 m.p.h. (110 knots) I.A.S., which is the safety speed when taking off without flaps, then throttle back to climbing boost and reduce to climbing r.p.m. With 20° flap, safety speed is 115 m.p.h. (100 knots) I.A.S.
- (iv) At a safe height of 600–800 feet raise the flaps.

### 45. Climbing

The speed for maximum rate of climb is initially 130 m.p.h. (115 knots) I.A.S.

### 46. General flying

- (i) *Stability*: The aircraft is directionally and longitudinally stable, with only slight stability on the climb. Laterally, depressing a wing causes the nose to drop, with slow recovery of the wing.
- (ii) *Controls*: When flying in bumpy weather, pilots may experience a slight "kick" on the controls, originating from the elevator and rudder. This does not interfere in any way with the control of the aircraft and can be ignored.
- (iii) *Change of trim*:

Undercarriage down .. .. .	Nose slightly down
Flaps down .. .. .	Nose up

The change of trim on lowering flaps is reduced by the permanent interconnection of the elevator trimming tabs with the flaps, but is not entirely eliminated. It is essential that the elevator trimming tab control *should not be forward of the central position* before the flaps are lowered, or damage to the tab control mechanism may result. On some aircraft a spring catch is fitted which allows the pilot to feel the central position on moving the control.

- (iv) *Flying at low airspeeds*: At speeds below 125 m.p.h. (110 knots) I.A.S. it is more pleasant to fly with the flaps lowered 20°.
- (v) *Oil cooler shutters (Mark III aircraft only)*: When operating in cold air conditions, the shutters must be used to maintain a normal oil inlet temperature. If left fully open in very cold conditions the coolers will freeze and give high temperatures, in which case the shutters must be closed fully for a short period and then partially opened.

## PART II—HANDLING INSTRUCTIONS

### 47. Stalling

- (i) The stall with flaps and undercarriage down is normal. One wing usually drops fairly quickly, and as the aircraft heels over, the nose falls below the horizon.
- (ii) *Stalling speeds in m.p.h. (knots) I.A.S.*:

	28,000 lb.	34,500 lb.
Flaps and undercarriage up . .	70 (60)	78 (67)
Flaps and undercarriage down	58 (50)	64 (55)

### 48. Diving

- (i) Leave the propeller speed controls at the cruising setting and (with electric propellers) the selector switches in the AUTO position.
- (ii) The aircraft should not be trimmed into the dive, but pushed into the dive. If it is trimmed in, excessive backward pull on the control column is necessary at high speeds.
- (iii) Ease out of the dive very slowly and open the throttles gently to avoid momentary overspeeding.

### 49. Check list before landing

Auto-pilot .. .. .	Cock—OUT
	Main switch—OFF
Brake pressure .. .. .	100 lb./sq.in. (minm.)
Carburettor air intakes ..	COLD
Gills .. .. .	CLOSED
Elevator trimming tabs ..	Neutral
	(see para. 46(iii))
Superchargers .. .. .	MEDIUM
Reduce speed to 140 m.p.h. (120 knots) I.A.S.	
U—Undercarriage .. .. .	DOWN (check by lights and horn)
M—Mixture controls .. ..	NORMAL
P—Propeller controls .. ..	Levers fully forward
	Selector switches—AUTO
F—Fuel .. .. .	Nacelle tanks on
	Flaps may be lowered to the take-off position at 140 m.p.h. (120 knots) I.A.S.
	Reduce speed still further to 120 m.p.h. (105 knots) I.A.S.
F—Flaps .. .. .	Fully DOWN

## PART II—HANDLING INSTRUCTIONS

### 50. Approach

- (i) Recommended approach speeds in m.p.h. (knots) I.A.S. are:

	26,000 lb.	29,000 lb.
Engine assisted .. ..	85 (75)	90 (80)
Glide .. ..	100 (85)	105 (90)
Flapless—engine assisted ..	105 (90)	110 (95)

- (ii) If a flapless approach is necessary, trim well back and come in low with plenty of engine.

### 51. Mislanding

- (i) The aircraft will climb with undercarriage and flaps down. At 28,000 lb. speed should be 90 m.p.h. (80 knots) I.A.S. until the flaps have been raised.
- (ii) Raise the undercarriage immediately.
- (iii) If the elevator tab control is aft of neutral it may be wound forward to central, but must not be forced past this position until the flaps have been raised.
- (iv) Raise the flaps a little at a time at a safe height of about 500 feet.

### 52. After landing

- (i) Raise the flaps and open the cowling gills.
- (ii) To stop the engines, head the aircraft into wind and allow the engines to cool; then open up gradually and run for five seconds at -2 lb./sq.in. boost. Close the throttle slowly to give 800-1,000 r.p.m., run at this speed for two minutes, then pull the slow-running cut-out controls.
- (iii) Switch OFF the ignition after the engine has stopped.
- (iv) Close the oil cooler shutters (Mark III aircraft only) and turn OFF all fuel cocks.
- (v) *Oil dilution* (see A.P. 2095):  
The dilution period for these aircraft is 4 minutes and the operation should be carried out at an engine speed not exceeding 1,000 r.p.m.

## PART II—HANDLING INSTRUCTIONS

### 53. Beam approach

- (i) The recommended speeds (m.p.h. (knots) I.A.S.), r.p.m., boost (lb./sq.in.) and flap settings are:

	Maintaining height		Final approach
	Preliminary manoeuvring	Manoeuvring with u/c down	
Speed Flaps	130 (115) 15°	130 (115) 15°	100-105 (85-90) 40° at O.M.B. Lower fully at I.M.B.
R.p.m.	2,000	2,400	Fully forward (AUTO)
Boost	-3	-1 to -2	-2 approx.

- (ii) For change of trim see Para. 46(iii).
- (iii) Approach at 600 feet over the O.M. Beacon, reducing to 100 feet over the I.M. Beacon.  
NOTE.—Altimeter reads 50 feet at 100 feet.
- (iv) Signal strength is best when flying parallel to the beam and weakest when flying away from it.

PART III

OPERATING DATA

54. Engine Data: Hercules XI (Mk. III aircraft only)

(i) Fuel.—100 octane. (The reduced limitations for use with 87 octane fuel are shown in brackets.)

(ii) Oil.—See A.P.1464/C37.

(iii) Engine limitations:

	R.p.m.	Boost lb./sq.in.	Temp. °C. Cyl. inlet	Oil inlet
MAX. TAKE-OFF TO 1,000 FT. .. M	2,800	+6½(+5)	—	—
MAX. CLIMBING 1 HR. LIMIT .. M } S }	2,500(2,400)	+3½(+2½)	270	90
MAX. RICH CONTINUOUS .. M } S }	2,500(2,400)	+3½(+2½)	270	80
MAX. WEAK CONTINUOUS .. M } S }	2,500(2,200)	zero	270	80
COMBAT 5 MINS. LIMIT .. M } S }	2,800	+6½(+5)	280	100

OIL PRESSURE:

NORMAL .. .. .	80 lb./sq.in.
MINIMUM .. .. .	70 lb./sq.in.

MINM. OIL TEMP. FOR TAKE-OFF .. .. . 5°C.

MAX. CYLR. TEMP. FOR STOPPING ENGINES 230°C.

PART III—OPERATING DATA

55. Engine Data: Hercules VI, XVI and XVII

(i) Fuel.—100 octane. (The reduced limitations for use with 87 octane fuel are shown in brackets.)

(ii) Oil.—See A.P.1464/C37.

(iii) Engine limitations:

	R.p.m.	Boost lb./sq.in.	Temp. °C. Cyl. inlet	Oil inlet
MAX. TAKE-OFF TO 1,000 FT. .. M	2,800*	+8½(+5)	—	—
MAX. CLIMBING 1 HR. LIMIT .. M } S }	2,400 2,500(2,400)	+6(+2½) +6(+2½)	270 270	90 90
MAX. RICH CONTINUOUS .. M } S }	2,400	+6(+2½)	270(250)	80
MAX. WEAK CONTINUOUS .. M } S }	2,400	+2†(zero)	270(250)	80
COMBAT 5 MINS. LIMIT .. M } S }	2,800	+8½(+5)	280	100

\*2,900 on Hercules XVII engines.

†Weak mixture on Hercules XVI and XVII engines is obtained by keeping at or below +2 lb./sq.in. boost.

OIL PRESSURE:

NORMAL .. .. .	80 lb./sq.in.
MINIMUM .. .. .	70 lb./sq.in.

MINM. OIL TEMP. FOR TAKE-OFF .. .. . 5°C.

MAX. CYLR. TEMP. FOR STOPPING ENGINES 230°C.

56. Flying limitations

(i) These aircraft are designed for manœuvres appropriate to a medium bomber and care must be taken to avoid imposing excessive loads in recovery from dives and in turns at high speeds.

Spinning and aerobatics are not permitted.

(ii) Maximum speeds in m.p.h. (knots) I.A.S.

Diving .. .. .	320 (280)
Leigh light lowered .. .. .	230 (200)
Undercarriage DOWN .. .. .	140 (120)
Flaps down to take-off position .. .. .	140 (120)
Flaps fully DOWN .. .. .	120 (105)
Landing lamps lowered .. .. .	100 (85)



PART III—OPERATING DATA

(iii) Maximum weights:

(a) Mark III aircraft:

Take-off and straight flying .. .. 34,500 lb.  
All forms of flying and landing .. .. 29,000 lb.

(b) Mark X, XI, XII, XIII and XIV aircraft:

Take-off and straight flying .. .. 36,500 lb.  
All forms of flying and landing .. .. 30,500 lb.

NOTE.—On Mark X, XI and XII aircraft on which Modification No. P.1603 has not been embodied the maximum A.U.W. is 34,500 lb.

The maximum landing weight for all Marks when used for training purposes is 29,000 lb.

(iv) Bomb clearance angles:

Diving .. .. 60°  
Climbing .. .. 20°

57. Position error corrections

From	100	130	140	150	170	190	200	220	240	} m.p.h. I.A.S.
To ..	130	140	150	170	190	200	220	240	270	
Add ..	12	10	8	6	4	2	0	—	—	} m.p.h. m.p.h.
Subtract	—	—	—	—	—	—	0	2	4	
From	85	110	120	130	145	165	170	190	205	} knots I.A.S.
To ..	110	120	130	145	165	170	190	205	230	
Add ..	12	10	8	6	4	2	0	—	—	} knots knots
Subtract	—	—	—	—	—	—	0	2	4	

NOTE.—When the A.S.I. is connected to the static vent the above corrections to airspeed can be ignored.

58. Maximum performance

Mark III and X aircraft:

(i) Climbing: 130 m.p.h. (115 knots) I.A.S.

Change to S ratio when the boost has fallen by 3 lb./sq.in. (Mk. X aircraft: 2½ lb./sq.in.)

(ii) Combat: Use S ratio if the boost in M ratio is 3 lb./sq.in. below the maximum permitted.

PART III—OPERATING DATA

59. Economical flying (see curves Page 32)

(i) Climbing:

Fly at 130 m.p.h. (115 knots) I.A.S. in rich mixture at maximum climbing boost and r.p.m. Change to S ratio when boost has fallen by 3 lb./sq.in. (Mark III and X aircraft only.)

To improve fuel consumption, if temperatures are not excessive, the boost should be followed back with the throttle as far as the economical cruising boost position (Hercules VI or XI), or to the midway position (Hercules XVI or XVII). A weak mixture climb at full load is not recommended, but when used change to S ratio when boost has fallen by 2 lb./sq.in.

(ii) Cruising:

(a) The recommended speeds m.p.h. (knots) I.A.S. are as follows:

Medium and high altitudes:

Fully loaded (outward journey) .. .. 155 (135)  
Lightly loaded (homeward journey) .. .. 140 (125)

Low altitudes:


For maximum range .. .. 160 (140)  
For maximum endurance .. .. 145-150 (125-130)

(b) Fly in weak mixture and M ratio at the maximum permissible boost (on some aircraft this position of the throttle lever is indicated by a white line on the lever coinciding with a pointer on the quadrant, pending the introduction of a warning light) and reduce speed by reducing r.p.m., which may be as low as 1,800 if this will give the recommended speed. If at 1,800 r.p.m. the recommended speed is exceeded, reduce boost.

(c) Engage S ratio when the recommended speed cannot be maintained at 2,400 r.p.m. (2,500 r.p.m. on Mark III aircraft if using 100 octane fuel), but not below 15,000 feet.

(iii) On Mark III aircraft the use of warm air intakes will not appreciably affect air miles per gallon, but on the later Marks they will be reduced by about 5½%.

(iv) The effect of small gill openings when cruising is insignificant.



60. Fuel capacities and consumption

(i) Capacities

(a) Normal:

Two front wing tanks	.. .. .	300 gallons
Two rear wing tanks	.. .. .	334 gallons
Two nacelle tanks	.. .. .	116 gallons

Total .. .. . 750 gallons

(b) Long-range (totals):

With one 140-gallon tank	.. .. .	890 gallons
With one 185-gallon tank	.. .. .	935 gallons
With one 140-gallon tank and two 55-gallon tanks	.. .. .	1,000 gallons
With two 140-gallon tanks	.. .. .	1,030 gallons
With one 295-gallon tank	.. .. .	1,045 gallons
With one 185-gallon tank and one 140-gallon tank	.. .. .	1,075 gallons
With three 185-gallon tanks	.. .. .	1,305 gallons

(ii) Hercules XI (Mark III aircraft only) fuel consumptions:

(a) The approximate total consumptions in RICH mixture are as follows:

<i>Boost</i>			
<i>lb./sq.in</i>	<i>R.p.m.</i>	<i>Galls./hr.</i>	
+6½	2,800	290	
+3½	2,500	222	

(b) The approximate total consumptions (galls./hr.) in WEAK mixture are as follows:

Boost lb./sq.in.	M ratio at 10,000 ft.			S ratio at 15,000 ft.		
	R.p.m.					
	2,400	2,200	2,000	2,400	2,200	2,000
0	117	—	—	111	104	—
-1	111	102	—	107	98	92
-2	104	96	85	101	92	87
-3	96	88	79	96	87	81
-4	87	81	73	90	81	75

For every 2,000 ft. above these heights add 1 gall./hr.  
For every 2,000 ft. below these heights deduct 1 gall./hr.

PART III—OPERATING DATA

(iii) Hercules VI, XVI and XVII fuel consumptions:

(a) The approximate total consumptions in RICH mixture are as follows:

Boost lb./sq.in.	R.p.m.	Galls./hr.
+8	2,900	320
+6	2,400	239

(b) The approximate total consumptions (galls./hr.) in WEAK mixture are as follows:

Boost lb./sq.in.	M <sub>4</sub> ratio at 5,000 ft.*				S ratio at 15,000 ft.			
	R.p.m.				R.p.m.			
	2,400	2,200	2,000	1,800	2,400	2,200	2,000	1,800
+2	118	110	102	94	116	110	106	96
0	106	98	92	80	104	100	96	88
-2	94	88	82	74	94	90	86	80
-4	84	80	74	68	86	82	78	—

For every 1,000 ft. above heights quoted add  $\frac{1}{2}$  gall./hr.

For every 1,000 ft. below heights quoted deduct  $\frac{1}{2}$  gall./hr.

\* For Hercules XVII engines these figures should be increased by five..

61. Static vent speeds

The following table shows the various handling speeds in m.p.h. and equivalent knots for aircraft with the A.S.I. connected to the static vent:

	M.p.h.	Knots
Take-off speed (minimum)	95	85
Safety speed—no flaps	135	120
Safety speed—20° flap	125	110
Climbing speed (initial)	140	125
Flying at low airspeeds (20° flap)	135	120

Stalling speeds:

At 28,500 lb.—all up	85-90	75-80
At 28,500 lb.—all down	70-80	60-70
At 34,500 lb.—all up	95-100	85-90
At 34,500 lb.—all down	80-90	70-80

PART III—OPERATING DATA

Circuit speeds:

Before lowering flaps	150	130
After lowering flaps	130	115

Approach speeds:

At 26,000 lb.—engine assisted	95	85
At 26,000 lb.—glide	110	95
At 26,000 lb.—flapless—engine assisted	115	100
At 29,000 lb.—engine assisted	100	90
At 29,000 lb.—glide	115	100
At 29,000 lb.—flapless—engine assisted	120	105

Mislanding .. .. . 100 90

Beam approach—initial .. .. . 140 125

Beam approach—final .. .. . 110-115 95-100

Maximum speeds:

Diving	310	270
Leigh light lowered	230	200
Undercarriage down	150	130
Flaps down to T.O. position	150	130
Flaps fully down	130	115
Landing lamp lowered	110	95

Economical flying:

Climbing	140	125
Cruising (Medium and high altitudes)		
Fully loaded	160	140
Lightly loaded	150	130
Cruising (Low altitudes)		
Max. range	165	145
Max. endurance	150-155	130-135

Engine failure during take-off .. 125 110

Single engine flight .. .. .  $\left\{ \begin{array}{l} 135 \\ 130 \end{array} \right. \begin{array}{l} 120 \\ 115 \end{array}$

Fuel jettisoning:

Flaps up	110	95
Flaps down 20°	135	120
Flaps fully down	90	80

## PART IV

## EMERGENCIES

## 62. Engine failure during take-off

- (i) With flaps 20° down the aircraft can be held straight if 115 m.p.h. (100 knots) I.A.S. has been attained.
- (ii) Any bombs, depth-charges, or torpedoes should be jettisoned. The propeller of the dead engine should be feathered and the gills closed.
- (iii) With the starboard engine failed it should be possible to climb away at about 31,000 lb. With the port engine failed performance is slightly inferior.

## 63. Engine failure in flight

- (i) Turn ON the fuel pressure balance cock (A). If the dead engine does not pick up, showing that the fuel pump is not the cause of failure, turn OFF the cock. If it is desired to run the live engine on the tanks in the opposite wing, it is necessary for the crew to open the suction balance cock (B).
- (ii) The propeller of the dead engine must be feathered and the gills closed.
- (iii) Fly in M ratio at 2,500 r.p.m. and +3½ lb./sq.in. boost (Mark III aircraft), or 2,400 r.p.m. and +6 lb./sq.in. boost (later Marks), at 125 m.p.h. (110 knots) I.A.S. (If using 87 octane fuel the r.p.m. and boost are 2,400 and 2½ lb./sq.in. respectively for all Marks of aircraft.) If necessary to maintain height, speed may be reduced to 120 m.p.h. (105 knots) I.A.S. Cylinder temperatures of the live engine must be watched and the gills opened as necessary. They should not be opened excessively as performance deteriorates. If temperatures do rise too high, increase speed.

## PART IV—EMERGENCIES

Climbing boost and r.p.m. should not be exceeded except to prevent dangerous loss of height. In tropical conditions 125 m.p.h. (110 knots) I.A.S. is the speed for minimum rate of descent.

- (iv) To maintain height at climbing power when using 100 octane fuel, weight must be reduced to approximately 28,500 lb. by jettisoning all bombs, depth-charges, or torpedoes, and, if necessary, some of the fuel load (see Para. 68). At 120 m.p.h. (105 knots) I.A.S., it should be possible to maintain height at 2,000 feet at this weight in temperate conditions. With full rudder trim a small amount of bank is required at this speed to reduce foot load.

## 64. Feathering

## (i) Rotol electric propellers:

- (a) Set the feathering switch to FEATHER. (If time is available, close the throttle first and then use DEC. R.P.M.)
- (b) Close the throttle immediately.
- (c) Set the selector switch central.
- (d) Switch off the ignition only when the engine has stopped.

## (ii) Rotol hydraulic propellers:

- (a) Set the propeller speed control fully back through the gate.
- (b) Close the throttle immediately.
- (c) Hold the button in until feathering is completed.
- (d) Switch off the ignition only when the engine has stopped.

## (iii) D.H. Hydromatic propellers:

- (a) Hold the button in only long enough to ensure that it stays in by itself; then release it so that it can spring out when feathering is completed.
- (b) Close the throttle immediately.
- (c) Switch off the ignition only when the engine has stopped.

## PART IV—EMERGENCIES

### 65. Unfeathering

#### (i) Rotol electric propellers:

(a) Set the throttle closed or slightly open, the propeller speed control fully down and switch on ignition.

(b) Set the feathering switch to NORMAL and hold the selector switch to INC. R.P.M. until about 1,000 r.p.m. are reached. Then set the selector switch to AUTO.

#### (ii) Rotol hydraulic propellers:

(a) Set the throttle closed or slightly open and switch on ignition.

(b) Set the propeller speed control just forward of the gate.

(c) Hold the button in until normal constant-speed operation is resumed. If unfeathering does not start when the button is depressed, set the propeller speed control slightly forward (to take up backlash).

#### (iii) D.H. Hydromatic propellers:

(a) Set the throttle closed or slightly open, the propeller speed control fully back and switch on ignition.

(b) Hold the button in until r.p.m. reach 1,000 to 1,300

(c) If the propeller does not return to normal constant-speed operation, open the throttle slightly.

### 66. Undercarriage emergency operation

(i) If the undercarriage cannot be lowered in the normal way, either by the engine-driven pump or the hand-pump, it may be lowered by the independent emergency hydraulic system in the following manner:

(a) Leave the undercarriage selector lever DOWN.

(b) Operate the catch release to free the lever (82) near the handpump. Raise the lever to the EMERGENCY (upper-most) position and leave it there.

(c) Lower the handpump handle to engage with the catches at the base of the pump.

(d) Operate the handpump. At least 250 double strokes are required.

## PART IV—EMERGENCIES

NOTE.—The emergency system will only lower the undercarriage. It will not raise the undercarriage nor operate the flaps or bomb doors. After using the emergency system the lever near the hand-pump may be returned to the normal position for an attempt to lower the flaps, but this will not be successful if the original failure of the main hydraulic system was due to loss of oil.

(ii) Should the green lights of the indicator not appear when the undercarriage is being lowered normally, it can be ascertained that the locks are engaged by using the hand-pump with the selector lever set to EMERGENCY. The high resistance which will finally be felt on the pump handle is an indication that the jack pistons are at the end of their travel and that the folding links are past dead centre, it being safe, therefore, to land. Except for this case of emergency, use of the handpump is not to be encouraged when the engine pump is functioning.

### 67. Bomb and Depth-charge jettisoning

(i) Open the bomb doors.

(ii) Jettison any small bomb containers first by operating the switch (75) on the starboard side of the cockpit.

(iii) Jettison the bombs or depth-charges by pulling the handle (2) on the port side of the instrument panel.

(iv) Close the bomb doors.

### 68. Fuel jettisoning

(i) Fuel in the four main tanks only may be jettisoned by first unscrewing the air vent valve wheel (51) on the left of the instrument panel four turns and then rotating the jettison valve wheel (52) immediately above to open. On later aircraft the two valves are operated by a single control. After jettisoning, the valves must be closed to maintain buoyancy or prevent fire. They can be closed if necessary when only part of the fuel has been jettisoned.

## PART IV—EMERGENCIES

- (ii) The average rates of jettisoning are as follows:
- (a) Flaps up at 100 m.p.h. (85 knots) I.A.S.: 100 gallons in 25 seconds.
  - (b) Flaps lowered 20° at 125 m.p.h. (110 knots) I.A.S.: 100 gallons in 20 seconds.
  - (c) Flaps fully down at 80 m.p.h. (70 knots) I.A.S.: 100 gallons in 15 seconds.

### 69. Parachute exits

When abandoning the aircraft by parachute the main entrance hatch and the starboard push-out panel immediately aft of the beam guns should be used as exits. A foot lever at the starboard side of the main entrance hatch enables the door to be opened independently of the door release handle. To gain access to the starboard push-out panel, a wooden guard or cover, fixed to the frame by press-studs, must be pulled away. The cover is inscribed **PULL OFF COVER FOR ACCESS TO EMERGENCY EXIT.**

### 70. Crash exits

In addition to the foregoing exits, roof exits are provided in the pilot's cockpit and at the sextant station. In the former, two outwardly-opening doors in the cockpit roof are released by a central lever and in the latter the sextant dome is released for opening downwards by either of two spring-loaded bolt levers at the front and rear of the mounting. These exits, together with the other unobstructed exits, can be used by the crew in the event of a crash-landing.

### 71. Air/sea rescue equipment

- (i) A "J" type dinghy is stowed in the starboard engine nacelle and is secured by a painter of 150 lbs. breaking strength. It may be inflated and released by any of the following methods:
- (a) Manually by pulling the handle inside the fuselage at the top of the rear face of the main spar, on the extreme starboard side. A sustained direct pull towards the centre of the aircraft is necessary.

## PART IV—EMERGENCIES

- (b) By ripping the fabric patch on the top surface of the starboard wing, about 2 feet from the fuselage side, immediately behind the main spar. This exposes a handle which is retained in spring clips immediately below the patch. A sustained pull upwards and inboard is necessary.
  - (c) Automatically by flooding of the immersion switch in the starboard engine nacelle.
- (ii) Certain aircraft have a small stowage for the dinghy permitting only the following items to be stowed with the dinghy: topping-up bellows, leak stoppers and drogue. On these aircraft the remaining air-sea rescue equipment is carried in a Type 5 and a Type 7 emergency packs (Stores References 27.C./1919 and /1931 respectively), these being stowed in the fuselage against the front spar. Their contents are given in the current Appendix A for the aircraft.
- (iii) On most aircraft, however, the dinghy compartment is larger, having the rear portion of the stowage floor stepped down, and a special emergency pack is carried in the stepped-down portion of the stowage and secured to the dinghy life-line by a lanyard. In addition, a Type 7 emergency pack is stowed inside the fuselage, aft of the front spar.

### 72. Flotation gear

Fourteen inflatable flotation bags are stowed at the top of the bomb cells. These bags are inflated from three CO<sub>2</sub> cylinders stowed in the port and starboard inner planes, which are discharged separately by pulling each of three handles contained in a box attached to the rear of the spar centre section and covered by an inscribed tear-off patch.

An immersion switch, mounted immediately aft of the front turret, automatically inflates the flotation bags when immersed in salt water, but in view of the time lag and the fact that the bomb doors may collapse upon impact unless supported, the bags should be inflated by means of the

## PART IV—EMERGENCIES

manual controls while still in the air. Before inflating the flotation bags, the bomb doors must be opened and bombs, or depth charges, jettisoned and the doors then closed again.

NOTE.—Flotation gear is not fitted when torpedoes are carried.

### 73. Ditching

- (i) Bombs, depth-charges, or torpedoes should be jettisoned and the bomb doors then closed.
- (ii) The mid-under turret on Mk. XII and XIV aircraft should be retracted.
- (iii) The flotation bags should, if possible, be inflated at least five minutes before ditching, but not above 3,000 feet in altitude. A member of the crew should check by examination through the windows at the rear end of the bomb cell that the bags have been properly inflated and advise the captain accordingly.
- (iv) Flaps should be lowered 30°.

### 74. Turret external rotation

To gain access to them in an emergency, the front (if fitted) and rear gun turrets can be rotated to the central position by means of nearby external rotation valves in the hydraulic supply lines on the port and starboard sides of the fuselage respectively.

Each valve is brought into operation by forcing a wire-locked oil supply change-over lever into the ON position; the turret can then be rotated in either direction by operating the lever on the other end of the valve unit.

### 75. Fire extinguishers

Each engine nacelle is fitted with a Graviner-type fire extinguishing system operated by a corresponding push-button (19) on the instrument panel. Automatic operation is by impact and gravity switches inside the fuselage.

One or more portable extinguishers are stowed at convenient points within the fuselage.

## PART V

### ILLUSTRATIONS

	<i>Fig.</i>
Pilot's Instrument panel .. .. .	1
Cockpit—port side .. .. .	2
Cockpit—starboard side (from above) ..	3
Fuel system diagram .. .. .	4

PART V—ILLUSTRATIONS

KEY TO Fig. 1

1. Bomb steering indicator.
2. Bomb/depth charge jettison control.
3. Auto-controls pressure gauge.
4. Instrument flying panel.
5. Starter and booster coil pushbuttons—port engine.
6. Propeller feathering switch—port engine.
7. Port engine speed indicator.
8. Undercarriage warning horn test pushbutton.
9. Fuel contents gauges pushbutton.
10. Windscreen wiper controls.
11. Undercarriage indicator.
12. Boost gauges (two).
13. Starboard engine speed indicator.
14. Cylinder temperature gauges (two).
15. Propeller feathering switch—starboard engine.
16. Oil tank low-level warning lights (two).
17. Starter and booster coil pushbuttons—starboard engine.
18. Pneumatic pressure gauge.
19. Fire extinguisher pushbuttons (two).
20. Air temperature gauge.
21. D.F. indicator.
22. Fuel pressure warning lights (two).
23. Pilot's call light.
24. Flare launching warning light.
25. Suction gauge.
26. Oil pressure gauges (two).
27. Oil temperature gauge—starboard engine.
28. Boost gauge reversal control.
29. Flap control lever.
30. Compass.
31. Undercarriage selector lever.
32. Rudder pedal—starboard.
33. Windscreen de-icing pump.
34. Oil temperature gauge—port engine.
35. Rudder bar adjustment wheel.
36. Flap indicator.
37. Cowling gill controls (two).
38. Intercomm. microphone pushbutton.
39. Torpedo release pushbuttons (two).
40. Brake lever.
41. Brake locking slide.
42. Bomb release pushbutton.
43. Bomb doors control.
44. Landing lamps switch.
45. Bomb master switch.




FIG 1

PILOT'S INSTRUMENT PANEL

FIG 1





KEY TO Fig. 2

- |   |  |
|---|--|
| 46. Throttle levers.                    | 58. Pilot's heating diffuser.                      |
| 47. Throttle levers friction adjuster.  | 59. Elevator and rudder trimming tab control.      |
| 48. T.R.U. remote control.              | 60. Elevator trimming tab fine adjustment control. |
| 49. Undercarriage indicator switch.     | 61. Engine master cock controls (two).             |
| 50. Ignition switches.                  | 62. Map storage.                                   |
| 51. Fuel jettisoning air valve control. | 63. Fuel pressure balance cock (A) control.        |
| 52. Fuel jettisoning air valve control. | 64. Micro/telephone socket.                        |
| 53. Mixture control levers.             | 65. Aileron (port only) trimming tab control.      |
| 54. Supercharger control.               | 66. Landing lamp lowering lever.                   |
| 55. Carburettor air-intake control.     | 67. Auto-pilot control cock.                       |
| 56. Propeller speed controls.           | 68. Auto-pilot steering lever.                     |
| 57. Slow-running cut-out controls.      | 69. Auto-pilot attitude control.                   |

KEY TO Fig. 3

- |  |  |
|--|--|
| 70. Second pilot's footrest.               | 80. Second pilot's heating diffuser.             |
| 71. Second pilot's micro/telephone socket. | 81. Hydraulic handpump.                          |
| 72. Headlamp switch.                       | 82. Hydraulic handpump emergency selector lever. |
| 73. Recognition lights switch.             | 83. Heating control.                             |
| 74. Navigation lights switch.              | 84. Suction pump change-over cock.               |
| 75. Bomb container jettison switch.        | 85. Pilot's seat adjustment lever.               |
| 76. I.F.F. pushbuttons and master switch.  | 86. Entrance hatch handle.                       |
| 77. Sunblind storage.                      | 87. Second pilot's footrest.                     |
| 78. Electrical panel.                      | 88. Parachute and/or dinghy storages (two).      |
| 79. Second pilot's seat.                   |  |



